
# **MAJEXTAND INSTRUCTIONS**

#### **DESCRIPTION:**



#### **MAJEXTAND - Improves posture magically!**

**MAJEXTAND** was specifically invented to help people keep **GOOD CERVICAL & SPINAL POSTURES** while carrying their MacBooks(Laptops) On The Go. It's the world's thinnest and handiest MacBook(laptop) stand ever. It's thinner than a dollar, but can raise a MacBook(laptop) as high as an iMac(desktop) with 1 finger in 1 second and 6 adjustable positions!

- MacBook + MAJEXTAND = iMac On The Go
- Laptop + **MAJEXTAND** = Desktop On The Go

#### I. FEATURES:

- 1. Thinnest 1.7mm only, thinner than a dollar
- 2. Handiest 1 finger in 1 second operation, simple installation and removal
- 3. Extraordinary design, made by precision technologies
- 4. Easy adjustability for 6 ergonomic laptop positions
- 5. 3D phenomenal cooling system
- 6. Accompanied by 80°C heat-resistant and no-residue adhesive strips that can be easily removed and reattached to other laptops

#### **II. SPECIFICATIONS:**

- 1. Origin: Taiwan
- 2. Thickness: 1.7mm
- 3. Weight: 136grams
- 4. Dimension: L141mm x W140mm
- 5. 6 ergonomic laptop positions: 7.0cm 12.0cm
- 6. Material: zinc alloy & stainless steel, high wear resistance POM foot

## **III. CONTAINS:**

1 MAJEXTAND, 4 assistant rubber feet, 1 alcohol prep pad, 2 no-residue adhesive strips

#### **IV. Compatibility:**

Compatible with any MacBook(laptop) whose screen size is smaller than 18" and the bottom case is intact

#### **IV. Preparation:**

Step 1:

Make sure your laptop bottom case is fully intact. There is no **removable component** that may interfere with the installation. (See pic 3&4)






#### Step 2 :

Fully clean up the bottom case surface by using the attached alcohol prep pad. (See pic 5)



Step 3 :

Draw the rule lines on the bottom case surface where you want to fix the **MAJEXTAND**. We recommend you to centrally put the **MA-JEXTAND** and align it with the Green Line. (See pic 6-1) Please make sure the Logo Side is close to the Laptop's rear edge. (See pic 6-2)



**Caution:** Rule lines should be drawn by the pencil which is softer than HB hardness, harder pencil may scratch the bottom case's coating. The rule lines are strongly suggested before installing **MAJEXTAND** onto your laptop to avoid any improper installation.

## V. Installation:


# Step 1 :


Reconfirm the position of **MAJEXTAND** as recommended above. Please make sure the Logo Side is close to the Green Line. (See pic 7)



Step 2 :

Remove the release papers of adhesive strips and stick **MAJEXTAND** onto the laptop bottom case, then press the base frame firmly. (See pic 8&9)






**Caution:** The adhesive strips under the base frame are used particularly on hard surface like aluminum alloy and hard plastic cases. Soft surface materials like **silicone, TPU/TPE** or any other similar materials are not attachable.

#### VI. Lifting:


Put your finger into the center hole, then lift the Upper case(Logo side) all the way until hearing a "click" sound. This is the lowest eye level of laptop. (See "Pulling Direction Sign #1", pic 10&11)




**Caution: DO NOT** lift the Lower Case Side yet. If you pull this side only then the **MAJEXTAND** won't have enough strength to hold the laptop and may cause the laptop screen Backwards. When lifting the plates, please keep away your fingers from the **retractable plate ratchets**.

#### VII. Adjusting heights:

In order to achieve higher eye level. You can pull the retractable plate Step By Step which shown as "Pulling direction Sign #2", (See pic 12) and adjust 6-different-eye-levels. (See pic 13)



**Caution:** When adjusting the plates, please keep away your fingers from the **retractable plate ratchets**.



6 heights from 7.0cm to 12.0cm(measure from the lower edge of screen case)

(Pic 13)

#### VIII. Retracting:

Press the **lock buttons** of both sides, then push the **retractable plate(s)** back to its case. (See pic 14&15)






**Caution:** When adjusting the plates, please keep away your fingers from the **retractable plate ratchets**.

#### IX. Assistant rubber feet:

Stick the assistant rubber feet above the original feet to increase the original thickness, and the friction force of the front feet. Make sure the longer feet are attached with right direction, and align with the front edge of laptop as shown in pic 16. (See pic 16)




(Pic 16)

#### X. Removal:

1. Use an **invalid credit card** or a card with similar textures.

2. Put the card into the gap between the base frame and the laptop bottom case, then slide it to the adhesive strip. (See pic 17)

3. Then slide the card slowly from one side to the other side to remove the adhesive strip from the bottom case. (See pic 18 & 19)



**Caution:** Please **hold MAJEXTAND firmly** while removing the adhesive strips. It can prevent any possible injury from your laptop and **MAJEXTAND**.

# 如何移除你的頸大師筆電架: <u>https://www.youtube.com/watch?v=Lzzujd-ICGw</u>

如何安裝筆電腳墊: <u>https://www.youtube.com/watch?v=9yFlzK\_aix8</u>

如何安裝頸大師筆電架: <u>https://www.youtube.com/watch?v=WIqHEcyazlM</u>